
SUMP / CLARIFIER MAINTENANCE STANDARDS

Facilities that perform steam cleaning, pressure washing, caustic cleaning, solvent degreasing, car washing, or radiator repair may introduce pollutants such as oil, sediment, metals, and corrosive materials into the sewer system. Sumps and clarifiers require a regular maintenance schedule to remove these pollutants.

* Industries generating hazardous waste (oil or sludge) must store it in a D.O.T. approved waste drum for proper disposal.



SUMP INSPECTION

BE SURE TO CHECK:	MUST BE:
Oil Layer	≤ 60% of the distance D1
Sediment Layer	≤ 60% of the distance D2
Elbow Pipe	In place and securely attached
PH	Between 5.5 and 11.0 units

CAPACITY UNAVAILABLE (Oil and/or sediment layer is% of the distance to the outlet)	RESULT
≤ 25%	Good: No cleaning required
> 25% and <u><</u> 60%	Cleaning recommended soon
> 60%	Bad: Clean sump ASAP



For more information, please contact:

ENCINA WASTEWATER AUTHORITY

Source Control Department 6200 Avenida Encinas Carlsbad, CA 92011 Telephone (760) 438-3941